

SG Supply And Service

Tel: (+65) 6259 7857 E-mail: Sales@SGsands.com Website: www.SGsands.com

CA939 – Floor Standing Drinking Water Dispenser

Direct Pipe In 3 Temperature Drinking Water Dispenser With 4 Stages Purification Filtration System

A point of use (POU) direct pipe in model, instant auto refill drinking water dispenser, three temperature | hot | room | cold | floor standing water dispenser complete with 4 stages water filtration system, specially designed for purification of your water source that fed to direct piping water dispenser . Purer & cleaner drinking water at home kitchen or office pantry. Visit our website www.SGsands.com for more products information and details specification.

✓ 4 Stages of Water Filtration				✓ 3 Choice of Water Temperature		
Sediment	Pre Carbon	Bio Alkaline	Silver Carbon	HOT	ROOM	COLD
Storage Tank Capacity				Product Dimension		
Tank Size Total 17Liters	3 Liters (hot)	4 Liters (cold)	10Liters (room)	380mm (width)	400mm (depth)	1050mm (height)



Model: CA939

CA939 Hot Room & Cold Floor Standing Water Dispenser

Product Features :

- ✓ Double secure prevent from overheat or dry-heat. (by sensor and thermostat).
- ✓ Double secure against water overflow. (by sensor and floating valve).
- ✓ Automatic control for purified water refill.
- ✓ Each boiling, ambient and chilled water has its own individual tank.
- ✓ Hot water tap with safety lock device.
- ✓ Color: Black

Product Specification :

- Heating capacity: 10L / hour.
- Hot water temperature can be assigned (at 82C, 85C, or 90C)
- Re-boil function up to 100 degree C.
- Chilling capacity: 20L / hour, chilled water under 10 degree C.
- Chilling system by compressor with R-134a refrigerant.
- Capacity : Cold: 4 Liters / Hot: 3 Liters / Room: 10 Liters
- Dimension : 380mm (width) x 400mm (depth) x 1050mm (height)

SG Supply and Service (Sgsands) supply and provide repair, replacement, maintenance, rental, and installation services for all your drinking water equipment. Including instant auto refill direct pipe in floor standing counter top wall mount Hot and Cold Water Dispensers, Water Cooler, Hot Water Boiler Dispenser, Bottled Type Water Dispenser, Reverse Osmosis RO Water Systems, Alkaline Water System, Energy Water System, Water Filters Cartridges & Housing, Purifier & Filter Fittings & Accessories.

Visit our showroom to view our latest range of water dispenser & cooler.

Call us @ 6259 7857 for a free no obligation quotation and promotion package.

Benefits of Direct Pipe In Drinking Water Dispensers

- Cost Effective Save Money
- Clean Filtered Quality Water
- No Storage No Dry Up
- Go Green Save The Earth



SG Supply And Service

Sales Enquiry HotLines : 6259 7857

Fax: 6725 8438 Website: www.SGsands.com Email: Sales@SGsands.com

Office / Showroom: Block 637, Veerasamy Road, #02-105, Singapore 200637